

Project SunToWater Tecnologies

In this document we are going to explain how to create and configure a site-to-site VPN.


We begin by deploying two PfSense and two windows 10 machines, in this case a machine from SunToWater and other from GlobeX, two machines separated by many miles away.




Next step is to configure each PfSense in order to accomplished the Site to site vpn. Open the PfSense Web configuration by using the Lan IP. **These steps must be made in both PfSenses (the ip address of the web configurator will be different)**



Next we need to enter "Interfaces" and choose "WAN"




And in the same page uncheck "Block private networks and loopback addresses" and "Block bogon networks"




Next we are going to "VPN" in the top menu, next "IPsec" and choose "Advanced Settings".

In these settings IKE SA should be "Diag", IKE Child SA should be "Diag" and configuration backend should be "Diag", everything else must be "Control".



Next we are going to choose "Tunnels" option and click on the green button "+ Add P1". In this phase we are going to create a tunnel.




In these steps we have to make sure that every option is ok.

Make a Description.

Set the Remote Gateway to the other PfSense WAN IP.

TIP: While configuring the other Pfsense the WAN Ip will be the other way around.

Authentication Method: "Mutual PSK"




In the same page we will encounter more configurations.


After the Authentication Method, we have to Generate a new pre-shared Key, this key will be the same in both PfSenses.

Encryption Algorithm will be "AES" with "256 bits" and "SHA256"

Life Time: "28800"



Then we must Save configurations and enter "Phase 2"




In this configuration we are going to:

Make a "Description", then:

Verify if "Mode" is on Tunnel IPv4, check:


If "Local Network" is on Lan subnet and:

Remote Network: <u>Network - (the IP address mut be the network of the Lan of the other Pfsense).</u>



In the same page we need to check if:


Procol is on "ESP", the on Encryption Algorithms "AES" is on 256 bits, the "PFS Key Group" is on 14 (2048 bit), and finally the "Life Time" on 3600.




In the next step we must save these configurations and verify that were really saved.

After saving previously configurations we need to:

In top menu choose "Firewall", then choose "Rules".



In Rules menu we need to choose "WAN" and add a "rule".



In this rule we have to make sure the following firewall rules are correct.


Action must be on "Pass"

Interface must be "Wan"

Protocol we have to choose "Any"

Source must be "Any"

Destination must be "Any"



In Rules menu we need to choose "IPSEC" and add a "rule".

In this rule we have to make sure the following firewall rules are correct.


Action must be on "Pass"

Interface must be "IPsec"

Protocol we have to choose "Any"

Source must be "Any"

Destination must be "Any"




After saving these configurations we are ready to make the Tunnel work.


Next step we have to connect the VPN Tunnel by:

On top menu choose "Status", then "IPsec".

Make sure the IP addresses are OK and click "Connect P1 and P2s", you only need to press this button only in one machine. If the Tunnel is well configurated it will connect automatically.




If everything was correct, congratulations we have a tunnel.




With the tunnel working we have to verify if que two machines can communicate with each other. We can check this by a command in "cmd", ping each other IP's.


If everything is ok we should get a reply from the other machine.




With the two machines working we must access each other folders.



With this done we can create, modify, and copy shared data.



And in the other end, check if it was really created and simply verify the files.



The End!